RISO, INC.
300 Rosewood Drive, Suite 210, Danvers, MA 01923 Telephone (508) 777-7377 Fax (508) 777-2517

TECHNICAL INFORMATION

TO: Dealer Technical Dept.

FROM: RISO, Inc. Technical Dept.

SUBJECT: Thermal Head Power Setting Guide For (H) Type Master

DATE: 4/28/88

ISSUE: T-19

The following reference chart should be used when replacement of thermal head or IT I/O PCB requires replacement.

NOTE:
Please add and use the chart with pages 3-43 through 3-45 in 2700 technical manual.

The Value of Resistance (Ω)	1st Pulse	2nd Pulse
1584 ~ 1626	01C	017
1627 ~ 1650	01D	017
1651 ~ 1681	01D	018
1682 ~ 1718	01E	018
1719 ~ 1737	01E	019
1738 ~ 1785	01F	019
1786 ~ 1792	01F	01A
1793 ~ 1847	100	01A
1848 ~ 1853	101	01A
1854 ~ 1902	101	01B
1903 ~ 1920	102	01B
1921 ~ 1957	102	01C
1958 ~ 1988	103	01C
1989 ~ 2013	103	01D
2014 ~ 2055	104	01D
2056 ~ 2068	104	01E
2069 ~ 2123	105	01E
2124 ~ 2178	106	01F
2179 ~ 2190	107	01F
2191 ~ 2234	107	100
2235 ~ 2258	108	100
2259 ~ 2289	108	101
2290 ~ 2325	109	101
2326 ~ 2344	109	102
2345 ~ 2393	10A	102
2394 ~ 2399	10A	103
2400 ~ 2455	10B	103